



Dancing Spinning Tops

Aim: To make a wooden spinning top

Materials

-Scissors -Textas -1 x 5cm hollow piece of bamboo

-35cm piece of string - Masking tape - Large wooden bead

-Round wooden disk -PVA glue - 6mm dowel rod x 7cm

Method

- 1. Decorate one side of the wooden disk by drawing patterns using textas.
- 2. Sharpen one end of the dowel rod.
- 3. Put some glue in the hole of the wooden disk.



- 4. Insert the pointy end of the rod into the disk, ensuring it is sitting tightly and stable. Wipe off excess glue from the tip.
- 5. Use masking tape to hold the rod in place until the glue is set. (This step is optional)
- 6. Tie the piece of string to the wooden bead.
- 7. Wind the string around the rod.
- 8. Slip the hollow bamboo cover over the rod.
- 9. Hold the bamboo and pull the string.
- 10. Watch the spinning top dance across the floor.

